

Maintenance Schedule | SureColor® S-Series



	DAILY (when in operation)	WEEKLY	MONTHLY	AS NEEDED	LONG-TERM STORAGE (more than 30-day idle period)
Nozzle Check					
Shake White/Silver Ink Cartridges (S80600)					
Automatic Print Head Cleaning		Execute via Control Panel			
Shake Color Ink Cartridges					
Manual Print Head Cleaning					
Check for New Firmware/Software					
Cleaning Cycles					
Change Fabric Wiper Unit, Air Filtration Filters and Flushing Pad				Estimated every 3 months for standard user	
Grease Carriage Rail				When notified by printer control panel	
Flush Ink and use Cleaning Fluid					